

PRODUCT DESCRIPTION RC BEAMS & COLUMNS DESIGN

EN1992 - NEN-NA- BRL 0207

EN 1992-1-1 NEN-NA

DOCUMENT

This document is the elaboration of BRL 0207: 2014 chapter 4 Product description.

IDENTIFICATION

RC Beam and column BRL 2014 V 1.0/16

CERTIFICATE

BRL 0207:2014 -Rekensoftware voor betonconstructies

Version 06/03/2014

<http://www.kiwa.nl/upload/certificate/00090880.pdf>

Certificate No.



SUPPLIER

SCIA Group International nv
Industrieweg 1007
3540 Herk-de-Stad, Belgium
<http://www.scia.net>
Phone : (+32)013/551775

PROGRAM

SCIA Engineer
Release 16.0
01/06/2016
Modules: esacd.01.01

CODES

Main standard: NEN-EN 1992-1-1 + C2: 2011 en - Eurocode 2: Design of concrete structures - Part 1-1: General rules and rules for buildings (Published on 01-11-2011)

Corrections: NEN-EN 1992-1-1 + C2: 2011 en - Eurocode 2: Design of concrete structures - Part 1-1: General rules and rules for buildings (published 01-11-2011)

National Appendix: NEN-EN 1992-1-1 + C2: 2011 / NB: 2011 en - National Annex to EN 1992-1-1 + C2 Eurocode 2: Design of concrete structures - Part 1-1: General rules and rules for buildings (published 01-11-2011)

GENERAL

This product description is the elaboration of BRL 0207: 2014 chapter 4 Product Description.

It indicates which parts of the software are certified according to BRL 0207:2014 Annex I - Functionality.

Also you can check the Concrete Design - new 1D Solution for EN 1992-1-1 on the link below
<http://resources.scia.net/en/articles/concrete/newconcrete1dsolution.htm>

IDENTIFICATION AND MARKING

The product description (this document) is available directly at page [http://resources.scia.net/en/benchmarks/KOMO- ECEN- NEN- NA- for- SE.htm](http://resources.scia.net/en/benchmarks/KOMO-ECEN-NEN-NA-for-SE.htm) or can be downloaded as a PDF from [http://resources.scia.net/download/en/qa/KOMO- RC- Beams- Columns- EN1992-NEN-NA-BRL-0207.pdf](http://resources.scia.net/download/en/qa/KOMO-RC-Beams-Columns-EN1992-NEN-NA-BRL-0207.pdf)

The accompanying KOMO product certificate can be accessed directly via page [http://resources.scia.net/download/en/qa/KOMO- RC- Beams- Columns- EN1992-NEN-NA-BRL-0207_Certificate.pdf](http://resources.scia.net/download/en/qa/KOMO-RC-Beams-Columns-EN1992-NEN-NA-BRL-0207_Certificate.pdf)

FUNCTIONALITY DESCRIPTION

This module is a software program for design and checks of reinforced concrete beams and columns according to EN 1992-1-1 with Dutch National Annex.

For the installation and operation of the program refer to the Installation Guide and Reference manual. This is provided in:

- Online Help system accessible at <http://help.scia.net/16.0/en>
- HTML Help format in file esa.chm (installed with the program itself)
- PDF format via multiple files downloadable from <http://help.scia.net/16.0/en/#rou/download.htm>

FUNCTIONALITY SCOPE

The functionality of this Scope does not cover the whole standard as described in 'BRL 0207: 2014 Annex I – Functionality'.

This scope covers these functionality:

Bending with axial force - chapter 6.1

- Check - verification of cross section subjected to $N+M_y+M_z$
- Design - design of reinforcement area for cross section subjected to $N+M_y+M_z$

Shear - chapter 6.2

- Check - verification of cross section subjected to V_y+V_z
- Design - design of reinforcement area for cross section subjected to V_y+V_z

Torsion - chapter 6.3

- Check - verification of cross section subjected to $V_y+V_z + T$
- Design - design of reinforcement area for cross-sections subjected to $V_y+V_z + T$ Serviceability limit state control -

Serviceability limit state control - chapter 7

- Check-for Stress limitation, crack control and deflection control

Detailing of members and particular rules - chapter 9

- Check - check of reinforcement based on detailing provision
- Design - design of reinforcement based on detailing provision

SUPPORTED CROSS-SECTIONS

For the certified part, the cross sections are limited to :

- Rectangular and T section for **beams**
- Rectangular and Circular sections for **columns**.

Reference	Function type	Cross-section			
		Beam		Column	
		Rect.	T	Rect.	Circ.
Chapter 6.1 – Bending with or without axial force	Check	✓	✓	✓	✓
	Design	✓	✓	✓	✓
Chapter 6.2 – Shear	Check	✓	✓	✓	✓
	Design	✓	✓	✓	✓
Chapter 6.3 - Torsion	Check	✓	✓	✓	✓
	Design	✓	✓	✓	✓
Chapter 7- Serviceability limit state control	Check	✓	✓	✓	✓
Chapter 9 - Detailing of members and particular rules	Check	✓	✓	✓	✓
	Design	✓	✓	✓	✓

The following parts of 'BRL 0207: 2014 Annex I – Functionality' are considered:

Fully Supported ✓

Not Supported ✗

Partly Supported -

Status	Chapter/Article	Chapter / Comment
	NEN-EN 1992-1-1+NB(NL)	
	6	ULTIMATE LIMIT STATES (ULS)
	6.1	Bending with or without axial force
✓	(1)	<ul style="list-style-type: none"> For 1D elements (beams and columns) Check according to 6.5 is not applied
✓	(2)	
✓	(3)	<ul style="list-style-type: none"> There is option to select between the parabola or the bilinear stress-strain diagram. For reinforcement steel, the diagram with the inclined top branch is applied.
✓	(4)	
✓	(5)	Automatically by iterative method searching for plane of equilibrium.
✓	(6)	
✓	(9)NB(NL)	
✗	(10) NB(NL)	
	6.2	Shear
	6.2.2	Members not requiring design shear reinforcement
✓	(1)	
✓	(4)	
-	(5)	The shift rule of 9.2.1.3.(2) is applied.
-	(6)	<ul style="list-style-type: none"> The value β is not used. The formula (6.5) is applied in all cases.
	6.2.3	Members requiring design shear reinforcement
✓	(1)	
✓	(2)	
✓	(3)	
✗	(4)	Inclined shear reinforcement is not implemented.
-	(7)	The shift rule of 9.2.1.3.(2) is applied.
✗	(8)	
	6.3	Torsion Design procedure
	6.3.2	<i>Design procedure</i>
✓	(1)	The value $V_{ed,1}$ is not used
✓	(2)	Automatic calculation of angle theta.
✓	(3)	
✓	(4)	
✓	(5)	
	7.	SERVICEABILITY LIMIT STATES (SLS)
	7.1.	General
✓	(2)	
	7.2.	Stress limitation
✓	(2)	
✓	(3)	
✓	(5)	Conditions for k_4 and k_5 are not applied.
	7.3.	Crack Control

Status	Chapter/Article	Chapter / Comment
	7.3.1.	General considerations
✓	(5)	
	7.3.4.	Calculation of crack widths
✓	(1)	
✓	(2)	
✓	(3)	
	7.4.	Deflection control
	7.4.1.	General considerations
✓	(4)	
✓	(5)	
	7.4.3.	Checking deflections by calculations
✓	(3)	
✓	(5)	
	9	DETAILING OF MEMBERS AND PARTICULAR RULES
	9.2	Beams
	9.2.1.	Longitudinal reinforcement
	9.2.1.1	Minimum and maximum reinforcement areas
-	(1)	<ul style="list-style-type: none"> • Standard EN1992 regulations are supported. • The application of the NEN NA is under construction.
✓	(3)	The limitation on A_s max is applied in all cases.
	9.2.2.	Shear reinforcement
✓	(1)	
✓	(5)	
✓	(6)	
	9.2.3.	Torsion reinforcement
✓	(2)	
✓	(3)	
✓	(4)	
	9.5.	Columns
	9.5.2.	Longitudinal reinforcement
✓	(1)	
✓	(2)	
✓	(3)	
✓	(4)	
	9.5.3.	Transverse reinforcement
✓	(1)	
✓	(3)	

USABILITY

SCIA Engineer program can be run on the following minimum hardware:

Minimum hardware requirement	
Processor Minimum	Intel Core2Duo or AMD equivalent Advised: Intel Core-i5 or AMD equivalent
RAM	2 GB (Advised: > 4 GB)
Graphics Controller	256 MB, supporting OpenGL
Free disk space	5GB
resolution	1280 x 800

Specific knowledge for use of the software:

1. College or university degree, or civil engineering (construction) direction, or equivalent.
2. Good knowledge of the Eurocode building standards relevant to computations,
3. Minimum of 2 years of practical experience with calculations according to the EN 199x series (EN 1992 for concrete),
4. Ability to make independent (concrete) calculations and / or verify,
5. Adequate knowledge of the specifications and operation of SCIA Engineer.

MAINTAINABILITY

SCIA Engineer is a modular system and each user can select his/her own configuration. An example of a combination of base modelling module (esa.00), static linear calculation module (esas.00), practical reinforcement module (esacdt.01) and EN1992 code design module (esacd.01.01).

WARRANTY

- SCIA guarantees that software will function in accordance with the written specifications, properties and functions as delivered to the client. Based on this guarantee, SCIA will detect and repair, free of charge, possible mistakes or failures in the program, which occur within the guarantee period of 6 months after delivery and which have been clearly announced in writing to SCIA within one month after discovery of them and this within the briefest possible delay.
- Should it be the case that, after investigation by SCIA, the cause of the failure, mentioned in the previous item, lies in the computer system or otherwise with the client, than the client will have to pay to SCIA all expenses linked to this investigation.
- SCIA is not responsible for the whole, hardware and software, for installations, in which the hardware has not been delivered by SCIA, unless extensive tests have been executed and unless a reasonable compensation for potential hidden hardware defects have been agreed to.
- The guarantee, mentioned in this item, terminates if the client, without written consent of SCIA, which will not be denied to the client on good grounds, makes alterations to the program or have alterations introduced by third parties.
- The activities of SCIA, performed on request of the client, which are not included in the delivery and/or maintenance contract, e.g. testing the software or hardware of third parties, literature search, support for operating systems, etc., can be charged at fixed rates.

LICENSE

The software is protected and can only be used with a valid license key. After purchasing the program and possible extra modules the license is recorded and the user is given a choice of hardware or software license key.

MAINTENANCE CONTRACT

When purchasing the software the user can sign also a maintenance contract. The maintenance contract gives the user the right to obtain free new versions (updates or patches) and to contact freely the helpdesk for questions and assistance in using the software.

From the moment when the maintenance contract is terminated, the user is no longer entitled to obtain free new version and continues to use the latest released version available prior to the termination date. The user also loses the right to contact the helpdesk for support.

COMMUNICATIONS

The software can be downloaded from SCIA website([Http://www.scia.net/en/software/product-selection/scia-engineer](http://www.scia.net/en/software/product-selection/scia-engineer)).

For this, the user must create an account as shown in these images

CHOOSE YOUR SOFTWARE

Product *

CONTACT DETAILS

Salutation *

First Name *

Last Name *

Email Address *

Phone *

ORGANISATION DETAILS

Organisation *

Address *

Zip Code *

City *

Country *

Comments

eNews Subscription Sign me up.

SUBMIT

CUSTOMER SERVICE

Message about new updates	Notification about a new versions of the software is made directly in the SCIA Engineer GUI.
Installing Updates	SCIA Engineer "new versions", "updates" and "patches" are always released as "complete setup".

PORTABILITY

Supported Windows OS	Windows 7 32/64 bit Windows 8 32/64 bit Windows 10 32/64 bit	
Supported Macintosh OS	You must run a virtualized version of Windows on OS X. We recommend Parallels Desktop (version 7 or higher). With this software you can install windows as a virtual machine on which you can run Windows application such as SCIA Engineer.	
API link with Revit	SCIA Engineer 16 is compatible with:	Revit 2013 Revit 2014 Revit 2015
API link with Tekla	SCIA Engineer 16 is compatible with: Tekla Structures 16, 32/64 bit Tekla Structures 16, 32/64 bit	Tekla Structures 17, 32/64 bit Tekla Structures 18, 32/64 bit Tekla Structures 19, 32/64 bit Tekla Structures 20, 32/64 bit
Etabs	SCIA Engineer 16 is compatible with: Etabs 9.2	
IFC	SCIA Engineer 16 is compatible with: IFC version 2x3	
SDNF	SCIA Engineer 16 is compatible with: SDNF version 2.0, SDNF version 3.0	

DEPENDENCIES

Standalone protection

The dongle must be accompanied with LIC file and in some cases also E2C file. Dongle itself is not sufficient for starting the SCIA Engineer.

To simplify as much as possible updating of dongles, working with dongle on more computers and other similar use cases it is possible to download LIC and E2C files online from the SCIA server.

Floating protection

SCIA Floating protection is based on FLEXnet technology of Flexera Software Company. This type of licensing stores commercial modules in "Trusted storage" on the Licence server. Those modules can be used (Checked out) by SCIA application online or borrowed (offline using of modules from licence server).

FLEXnet based protection fully replaces FlexLM based protection from version 2010.0.

Trial, Student and Viewer modes

It is also possible to run SCIA Engineer without protection as SCIA Viewer. In this case SCIA Engineer has limited functionality. It is intended to be used for viewing of calculated structures only. The user can also use "TRIAL" or "STUDENT" modules which are also free but still require some modules.

Student version

- User can use majority of all SCIA Engineer functionality.
- User can edit and calculate a project
- Projects can be saved as *.esad only
- Available for free for registered users (students) only

Trial version

- User can use functionality listed in his licence file only
- User can edit and calculate a project
- Projects are saved into *.esa
- Provided by SCIA dealers to prospect customers

SCIA Viewer version

Available from version 2011

- User can view existing model and document only
- User cannot edit nor calculate a project
- If the project is saved with results then user can view pre calculated checks
- Projects cannot be saved neither exported to any file format
- Available to anybody without any protection

PRODUCT CERTIFICATE

The version of SCIA Engineer which the KOMO product certificate has been granted to can be seen on the cover page.

Required modules

esacd.01.01

esa.00

References and related reading

Analysis of second order effect in concrete (*Technical article*)

Wizard for reinforcement schemes (*Technical article*)

Design of concrete members (*SCIA Engineer Help*)